



DEVICE SUPPORT LIST - AP-114 Universal Hardware Platform AVR-isp In-System Programming Support

32-bit AVR UC3

AT32uca0512

megaAVR - AT90

AT90S1200	AT90S2313	AT90S2333	AT90S2343
AT90S4414	AT90S4433	AT90S4434	AT90S8515
AT90S8535	AT90CAN128	AT90CAN32	AT90CAN64
AT90PWM2	AT90PWM2B	AT90PWM3	AT90PWM3B

megaAVR - Atmega

ATmega103	ATmega128	ATmega1280	ATmega1281
ATmega1284P	ATmega1286	ATmega1287	ATmega128RFA1
ATmega16	ATmega161	ATmega162	ATmega163
ATmega164	ATmega164P	ATmega168	ATmega169
ATmega2560	ATmega2561	ATmega32	ATmega324P
ATmega325	ATmega3250	ATmega328P	ATmega329
ATmega3290	ATmega329P	ATmega3290P	ATmega32U4
ATmega48	ATmega64	ATmega640	ATmega644P
ATmega644	ATmega645	ATmega647	ATmega6450
ATmega649	ATmega6490	ATmega8	ATmega82
ATmega8515	ATmega8535	ATmega88	

tinyAVR

ATtiny10	ATtiny12	ATtiny13	ATtiny15
ATtiny2313	ATtiny25	ATtiny26	ATtiny261
ATtiny4	ATtiny44	ATtiny45	ATtiny461
ATtiny5	ATtiny84	ATtiny85	ATtiny861
ATtiny88	ATtiny9		

XMEGA

ATxmega128A1	ATxmega128A1revD	ATxmega128A3	ATxmega128A4
ATxmega16A4	ATxmega192A1	ATxmega192A3	ATxmega256A1
ATxmega256A3	ATxmega256A3B	ATxmega32A4	ATxmega64A1
ATxmega64A3	ATxmega64A4		